


OPTIONAL INSTALLATION 4000W & 6000W MODELS



WARNING

240 V AC Single Phase
Heater must be permanently
installed and hard wired by an
authorised/licenced person.